

FAN CONTROL OPTIONS

Choose the Control Package That Suits Your Needs

ENVIRA-NORTH
SYSTEMS LIMITED

EssentialAIR FAN CONTROL

EssentialAIR
FAN CONTROL

VFD



- Wall Mounted Variable Frequency Drive (VFD) Configuration
- Minimal Distance Between VFD & HVLS Fan
- One Per Fan Required

ZoneAIR FAN CONTROL

ZoneAIR
FAN CONTROL

VFD



Mount Plate



Wiring Harness

- Fan Mounted VFD
- One ZoneAir Control Per Fan Required
- Package Includes Mounting Plate + Wiring Harness
- Designed to Provide a Single Control for Multiple Fans
- Requires Additional Controls

OPTIONS



LOW VOLTAGE CONTROL (LVC)

- Controls Groups of (up to) Seven (7) Fans
- Lockable Cover
- Stop Button
 - Forward/Reverse
 - Speed Up/Down
 - Toggle Between Manual/Auto Modes

OPTIONS



TEMPERATURE CONTROL (TFD-1)

- Programmed for Automatic Fan Speeds
- Constantly Measures Temperature
- Automatically Adjusts to Your Set Points

CommandAIR FAN CONTROL

CommandAIR
FAN CONTROL

VFD



Remote Keypad



100' (30.48m)
CAT 5 Cable



Mount Plate



Wiring
Harness

- Fan Mounted VFD
- One CommandAIR Control Per Fan Required
- Package Includes Mounting Plate + Wiring Harness + Control Wire
- and Remote Keypad
- Provides Remote Troubleshooting for Fan Mounted VFD
- User Friendly, Simplified Installation and Operation

